

Bergen Round Dining Table


ASSEMBLY INSTRUCTIONS

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting. When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

PARTS INVENTORY		
ID	DESCRIPTION	QTY
1	TOP	1
2	BASE	1


HARDWARE INVENTORY				
ID	IMAGE	DESCRIPTION	SIZE	QTY
A		ALLEN BOLT	M6 x35mm	4
B		LOCK WASHER	15 x 10mm	4
C		FLAT WASHER	22 X 10mm	4
D		ALLEN WRENCH	M4 X 110mm	1



JOON LOLOI

STEP 1

Place the **TOP (1)** upside down on a flat surface. Place **BASE (2)** above **TOP (1)**, ensuring the bolt holes are properly aligned. Slide a **LOCKWASHER (B)**, followed by a **FLAT WASHER (C)**, onto an **ALLEN BOLT (A)**. Secure the **BASE (2)** by using the **ALLEN WRNECH (D)** to tighten the **ALLEN BOLT (A)**. Repeat this process for four corners.



STEP 2

Flip the Bergen Round Dining Table right side up. Assembly is now complete.

