


Dalton Drum Coffee Table


ASSEMBLY INSTRUCTIONS

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting. When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

PARTS INVENTORY		
ID	DESCRIPTION	QTY
1	TOP	1
2	LEGS	4


HARDWARE INVENTORY				
ID	IMAGE	DESCRIPTION	SIZE	QTY
A		ALLEN BOLT	6 x 20mm	16
B		FLAT WASHER	6 x 16mm	16
C		SPRING WASHER	6 x 16mm	16
D		ALLEN KEY	4mm	1



JOON LOLOI

STEP 1

Place the **TOP (1)** face down on a flat surface. Position the **LEGS (2)** on both sides of the **TOP (1)**. Align the holes on each **LEG (2)** with the holes on the **TOP (1)**. Slide a **FLAT WASHER (A)** onto an **ALLEN BOLT (B)**, then secure them using the **ALLEN WRENCH (C)**. Repeat this process for all remaining legs. Do not over tighten bolts.



JOON LOLOI

STEP 2

Once all the bolts are secured, turn the coffee table right side up. Check for stability and adjust floor levelers at the bottom corners of your table as needed. Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture.

