# Kirkby Coffee Table


**ASSEMBLY INSTRUCTIONS** 

#### **ASSEMBLY INSTRUCTIONS**

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting. When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.


	PARTS INVENTORY	
ID	DESCRIPTION	QTY
1	TOP	1
2	LEGS	4

HARDWARE INVENTORY						
ID	IMAGE	DESCRIPTION	SIZE	QTY		
A		ALLEN BOLT	M6 X 16mm	16		
B		FLAT WASHER	Ø16mm x Ø8mm	16		
0		ALLEN KEY	4mm	1		




#### STEP 1

Turn the **TOP (1)** upside down and place the **LEGS (2)** on the Top, ensuring all bolt holes are aligned with the metal plate.




#### STEP 2


Slide FLAT WASHER (B) onto the ALLEN BOLT (A). Align the bolt holes on the LEGS (2) with the TOP (1) and attach them using ALLEN WRENCH (C). Repeat this process for all four legs.



#### STEP 3

Turn the coffee table right side up after tightening all the bolts.





#### STEP 4

Once all components have been secured, adjust levelers, and the assembly is complete.

