




Kolby Oak Dining Table


ASSEMBLY INSTRUCTIONS

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting. When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

PARTS INVENTORY		
ID	DESCRIPTION	QTY
1	TOP	1
2	LEGS	2


HARDWARE INVENTORY				
ID	IMAGE	DESCRIPTION	SIZE	QTY
A		ALLEN BOLT	M6 X 16mm	16
B		FLAT WASHER	Ø16mm x Ø8mm	16
C		ALLEN KEY	4mm	1



JOON LOLOI

STEP 1


Turn the **TOP (1)** upside down and place the **LEGS (2)** on the Top, ensuring all bolt holes are aligned with the metal plate.



JOON LOLOI

STEP 2



Slide **FLAT WASHER (B)** onto the **ALLEN BOLT (A)**. Align the bolt holes on the **LEGS (2)** with the **TOP (1)** and attach them using **ALLEN WRENCH (C)**. Repeat this process for both legs.



JOON LOLOI

STEP 3

Turn the dining table right side up after tightening all the bolts.



JOON LOLOI

STEP 4

Once all components have been secured, adjust levelers, and the assembly is complete.

