















Glenwood Cabinet



ASSEMBLY INSTRUCTIONS

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting. When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

| PARTS INVENTORY | | |
|-----------------|-------------|-----|
| ID | DESCRIPTION | QTY |
| 1 | SIDEBOARD | 1 |
| 2 | LEGS | 2 |
| 3 | HUTCH | 1 |


| HARDWARE INVENTORY | | | | |
|--------------------|--|-----------------|------------|-----|
| ID | IMAGE | DESCRIPTION | SIZE | QTY |
| A |  | ALLEN BOLT | M8 X 30mm | 6 |
| B |  | LOCK WASHER | 12 X 9mm | 14 |
| C |  | FLAT WASHER | 19 x 9mm | 14 |
| D |  | ALLEN WRENCH | 5mm | 1 |
| E |  | LEVELING GLIDE | M8 x 35mm | 4 |
| F |  | METAL PLATE | 3mm | 2 |
| G |  | METAL L BRACKET | 62 x 25mm | 1 |
| H |  | BOLT | M4 x 15MM | 1 |
| I |  | FLAT WASHER | 6 x 16mm | 2 |
| J |  | ANCHOR | Ø13 x 40mm | 1 |
| K |  | SCREW | M4mm | 1 |
| L |  | ALLEN BOLT | M6 x 15mm | 8 |
| M |  | SHELF PIN | 5mm | 4 |
| N |  | SCREW | M4 x 15mm | 4 |



JOON LOLOI


STEP 1

Place the **SIDEBOARD (1)** on its back so that the bottom can be easily accessed. Slide **LOCK WASHER (B)** and then **FLAT WASHER (C)** onto **ALLEN BOLT (A)**. Align the bolt holes on the **LEG (2)** and attach them to the bottom of the sideboard using **ALLEN WRENCH (D)** to screw in **ALLEN BOLT (A)**. Do this for all 3 bolts. Repeat the process for both legs.




STEP 2

The **LEVELING GLIDE (E)** is located at the bottom of the **SIDEBOARD (1)**. When you place the furniture in the desired position, you can adjust the **LEVELING GLIDES (E)** depending on the surface. Make sure it is level and stable. Once your sideboard is level, the assembly is complete.




STEP 3

The wooden adjustable shelf is attached to the **SHELF PIN (M)** for shipping. To change the position of the shelf, first remove the **SCREWS (N)** from the **SHELF PIN (M)**. Remove the shelf and relocate the **SHELF PIN (M)** to another set of pre-bored holes. Reinstall the shelf.



STEP 4


To change the position of the shelf on the **HUTCH (3)**, first remove the shelf and relocate it to another set of grooves.



JOON LOLOI

STEP 5

Place the **HUTCH (3)** on top of the **SIDEBOARD (1)**. Slide **LOCK WASHER (B)** and then **FLAT WASHER (C)** onto **ALLEN BOLT (A)**. Align the bolt holes on the **METAL PLATE (F)** and attach the back of the **HUTCH (3)** and **SIDEBOARD (1)** using **ALLEN WRENCH (D)**, to screw in **ALLEN BOLT (A)**. Do this for all 4 bolts. Repeat the process for both **METAL PLATES (F)**.



STEP 6

WARNING – THIS UNIT MUST BE FIXED TO THE WALL

First, mark the hole on the wall aligned with the position of the cabinet where you want to place it. Screw the **ANCHOR (J)** to the wall. Slide the **FLAT WASHER (I)** onto **SCREW (K)**. Align the holes on the **METAL L BRACKET (G)** and attach it to the anchor hole, then screw it in. Slide **FLAT WASHER (I)** onto **BOLT (H)**. Align the bolt holes on the **METAL L BRACKET (G)** and attach it to the top of the **HUTCH (3)** using a screwdriver to screw in **BOLT (H)**. Once all components have been secured, the assembly is complete.

