**Nelson Dining Table** 


**ASSEMBLY INSTRUCTIONS** 

#### **ASSEMBLY INSTRUCTIONS**

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting. When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

PARTS INVENTORY				
ID	DESCRIPTION	QTY		
0	ТОР	1		
2	LEGS	2		
3	STRETCHER	1		


HARDWARE INVEBTORY						
ID	IMAGE	DESCRIPTION	SIZE	QTY		
A		ALLEN BOLT	M8 x 20 mm	16		
В		ALLEN BOLT	M8 x 60 mm	4		
0		ALLEN BOLT	M6 x 40 mm	2		
0		FLAT WAHSER	8 x16 mm	20		
<b>3</b>	$\widehat{\bigcirc}$	HALF MOON WASHER	20x12x06 mm	2		
•		ALLEN KEY	4 mm	1		
G		ALLEN KEY	5mm	1		



MADE IN INDIA 2 of 7

### STEP 1


Turn the Top (1) Upside down and place the Legs (2) on top, ensuring all bolt holes are aligned with the metal plate.



MADE IN INDIA 3 of 7

#### STEP 2


Slide Flat Washer (D) onto Allen Bolt (A). Align the bolt holes on the Legs (2) with the Top (1) and attach them using Allen Wrench (G). Repeat this process for all central plates Align bolt holes to the top frame and secure Allen Bolt (B) using Allen Wrench (G). Repeat this process for remaining bolt holes.



MADE IN INDIA 4 of 7

### STEP 3

Center the stretcher (3) to the leg (2) and ensure it aligns to the dowel hole , Place the second Leg (2) component to align with the dowel hole.




MADE IN INDIA 5 of 7

#### STEP 4

Slide Flat Washer (D) onto Allen Bolt (A), Align the bolt holes on the Legs (2) with the Top (1) and attach them using Allen Wrench (G). Repeat this process for all central plates.


Align bolt holes to the top frame and secure Allen Bolt (B) using Allen Wrench (G). Repeat this process for remaining bolt holes. Secure the stretcher (3) to the Legs (2) with Allen Bolt (C), Moon washer(E) and tightening by using Allen Wrench (F).



MADE IN INDIA 6 of 7

#### STEP 5

Turn the dining table right side up after tightening all the bolts. Once all components have been secured, adjust levelers, and the assembly is complete.



MADE IN INDIA 7 of 7